

Chapter 1 : SAMSUNG HW-F USER MANUAL Pdf Download.

Samsung HW-F Pdf User Manuals. View online or download Samsung HW-F User Manual.

Table of Contents Page: To receive more complete service, please register your product at www.samsung.com.

Multi-function Remote Control The supplied remote control can be used to control the TV connected to this unit. Works only for Samsung TVs The remote control has a TV hotkey that enables you to perform various operations with the simple press of a button.

Active Speaker System This unit features an Active Speaker System that provides high sound quality in a single slim unit. This unit does not require any satellite loudspeakers or speaker cabling, which are normally associated with conventional surround sound systems.

Bluetooth Function You can use connect a Bluetooth device to the SAT and enjoy music with high quality stereo sound, all without wires! Dolby and the double-D symbol are trademarks of Dolby Laboratories. This symbol indicates important instructions accompanying the product. Do not put objects filled with liquids, such as vases on the apparatus. Consequently, the power plug must be easily and readily accessible at all times. Make sure the ventilation slots are not covered. Do not place the unit on amplifiers or other equipment which may become hot. This unit is designed for continuous use. To fully turn off the unit, disconnect the AC plug from the wall outlet. Unplug the unit if you intend to leave it unused for a long period of time. Voltage peaks due to lightning could damage the unit. Protect the product from moisture vases, coffee cups, etc. Your product is not intended for industrial use. This product is for personal use only. Condensation may occur if your product has been stored in cold temperatures. If transporting the unit during the winter, wait approximately 2 hours until the unit has reached room temperature before using. Do not expose the unit to direct sunlight or other heat sources. This could lead to overheating and cause the unit to malfunction. The batteries used with this product contain chemicals that are harmful to the environment. Do not dispose of batteries in the general household trash. The batteries used with this product contain chemicals that are harmful to

Phones Page: Icons used in this manual

Icon Term Definition

Caution Indicates a situation where a function does not operate or settings may be canceled.

Note Indicates tips or instructions on the page that help you operate a function.

Safety Instructions and Troubleshooting

1 Be sure to familiarize yourself with the Safety Instructions before using this product. See page 3

2 If a problem occurs, check Troubleshooting. To cancel MUTE button setup, press button for more than 3 seconds again. Do not pull the cable. Place the Subwoofer speaker cable on the opened core. Lift the cover at the back of the remote control upward as shown. Install two AAA size batteries. Assuming typical TV usage, the batteries last for about one year.

Operational Range of the Remote Control You can use the remote control up to 23 feet 7 meters in a straight line from the unit. Moves to the previous TV channel. MUTE Mutes the sound from the unit. Press again to restore the sound to the previous volume level. You can control the brightness of the Display. Adjusts the volume level of the unit. Used to help sync video to audio when connected to a digital TV. If the unit falls off, it may cause an injury or damage the product. If possible, fix the support screws into wall studs. Otherwise, it may cause an electric shock. Place the wall mount bracket on a wall surface and then secure it with two screws not supplied. If you are hanging the unit below a TV, be sure to install the wall mount bracket so that the arrow is placed in the center of the TV. Also make sure the unit is at least two inches 5 cm below the TV. Insert the supplied screws through the screw holders, and then screw them into the Main Unit. Insert the USB converter into the unit before installing it on the wall. Fit the unit into the corresponding slots of the wall mount bracket. For secure installation, make sure the mounting studs slide firmly down into the bottom of the slots. Press an appropriate button on the remote control to select a desired mode, or press to select one from: Input mode Display Optical Digital input D. Bluetooth is a technology that enables Bluetooth-compliant devices to interconnect easily with each other using a short wireless connection. If the distance exceeds the Bluetooth operational range, the connection is lost. The connection will be automatically cut off if the Bluetooth device is out of range. Even within range, the sound quality may be degraded by obstacles such as walls or doors. Connect Bluetooth device 1. Select the Bluetooth menu on the Bluetooth device you want to connect. Select the Stereo headset menu on the Bluetooth device. Select "[Samsung] AirTrack" from the list.

Play music on the connected device. To reconnect, you must pair the device again. Once the pairing is established, the pairing information is recorded and kept and no further Bluetooth connection message will appear. Bring the Air Track and the TV close together before pairing. The pairing with the Air Track will be completed. You can now pair it to a different TV. If this occurs, connect to the Bluetooth device again within the operational range. If set to Off, the product turns off automatically when the TV turns off, but it does not turn on automatically. Check whether your TV supports SoundShare before you begin. USB appears on the display screen and then disappears. Before you connect a USB device Be aware of the following: Otherwise, you may encounter a USB compatibility problem. It may not operate properly. Repeat playing a track. Repeat playing all tracks. A track that has already been played may be played again. To mute the sound of this unit, press the MUTE button on the remote control. Each time the button is pressed, the selection changes as follows: If this occurs, adjust the audio delay time to match the video. Using the DRC function This feature balances the range between the loudest and quietest sounds. You can use this function to enjoy Dolby Digital sound when watching movies at low volume at night. Press DRC on the remote control of this unit. The Air Track also controls the sound volume, sound quality, etc. If an upgrade is offered, you can upgrade the firmware by connecting a USB drive with the firmware upgrade stored on it to the USB port on your Air Track. Note that if there are multiple upgrade files, you must load them onto the USB drive singly and use them to upgrade the firmware one at a time. The main unit will turn off automatically after completing the firmware upgrade. When software is upgraded, settings you have made will return to their default factory settings. We recommend you write down your settings so that you can easily reset them after the upgrade. Symptom Check Remedy The unit will not turn on. A function does not work when the button is pressed. Sound is not produced. The Picture does not appear on a TV when the function is selected. The remote control does not work. The SoundShare TV pairing failed. Check your TV to see if it supports SoundShare.

Chapter 2 : Samsung HW-J W Channel Soundbar Speaker HW-J/ZA B&H

Get access to helpful solutions, how-to guides, owners' manuals, and product specifications for your Channel Sound Bar System with Wired Subwoofer (HW-F) from Samsung US Support.

Chapter 3 : Samsung Speaker System HW-F User Guide | www.nxgvision.com

Samsung HW-F Sound Bar user manual was written in English and published in PDF File (Portable Document Format). You can find helpful and important information or learn the basics of Samsung Sound Bar HW-F with its user manual, user guide and instruction manual.

Chapter 4 : Samsung HW-F Manuals

Page 1: User Manual. HW-F HW-F Crystal Surround Air Track (Active Speaker System) user manual imagine the possibilities Thank you for purchasing this Samsung product.

Chapter 5 : HW-F 40" Soundbar with SoundShare | Samsung Support UK

HW-F 40" Soundbar with SoundShare. Solutions & Tips, Download Manual, Contact Us. Samsung Support UK.

Chapter 6 : Samsung HW-F manual

Our goal is to provide you with a quick access to the content of the user manual for Samsung HW-F Sound Bar HW-F Using the online preview, you can quickly view the contents and go to the page where you will find the solution to your problem with Samsung HW-F Sound Bar HW-F

DOWNLOAD PDF SAMSUNG HW F355 MANUAL

Chapter 7 : Samsung HW-F Benutzerhandbuch | www.nxgvision.com

Audio manuals and audio service pdf instructions. Find the user manual you need for your audio device and more at ManualsOnline.

Chapter 8 : How to Install Samsung Channel Sound Bar Home Theaters | www.nxgvision.com

Samsung HW-F Manuals & User Guides. User Manuals, Guides and Specifications for your Samsung HW-F Speaker System. Database contains 2 Samsung HW-F Manuals (available for free online viewing or downloading in PDF): Operation & user's manual.

Chapter 9 : Samsung HW-F Specs - CNET

Read and download Samsung Speaker System Samsung HW-F Sound Bar HW-F User's Manual online. Download free Samsung user manuals, owners manuals, instructions, warranties and installation guides, etc.