

## Chapter 1 : Garmin Edge manual

*Edge Owner's Manual 3 Getting Started 2. Place the rubber disk on the back of the bike mount. The rubber tabs align with the back of the bike mount so it stays in.*

Edge software version 3. If updating from a software version prior to 3. This can cause the update process to take up to 15 minutes for devices with a large number of files on their device. To reduce this time, please remove older activity files from your device before updating. If this software is uploaded to a device other than that for which it is designed, you will not be able to operate that device. Change History Changes made from version 3. Added Vector power sensor support. Changes made from version 3. Fixed display of power meter serial numbers. Made changes to support manufacturing. Changes made from version 2. Added two additional training pages. Improved support for power-based workouts. Made improvements to the power meter calibration process. Fixed an issue where Auto Zero was incorrectly displayed as an option when paired to the PowerTap hub. Improved the calculation of time behind on the Virtual Partner page. Fixed various issues with viewing activities in history. Fixed various issues related to courses. Fixed various other issues. Fixed issue causing multiple heart rate monitors to be found. Fixed a speed display issue in history, speed zone setup, and workouts. Added one second recording setting. Fixed issue causing ANT sensors to not pair as expected when switching between bike profiles. Fixed a display issue with the elevation value in a saved elevation point. Improved course performance and corrected an issue that could cause some courses to stop processing. Added a torque reading to the calibration page for PowerTap power meters. Improved Auto Pause behavior. Improved auto wheel calibration especially for PowerTap power meters. Improved correlation of speed sensor data and GPS data. Totals can now be cleared. Corrected an issue that could prevent an Activity from being reset. Improved battery gauge readings. This page will allow the user to set the zooming to auto or to some set zoom level. Updated the Start Notice feature to alert the user any time the timer is not running if set to Repeat Fixed issue causing elapsed time to not be calculated correctly Delete Garmin software update files after updates are complete Updated translations Changes made from version 2. Internal file processing corrections. Changes to support manufacturing. Workouts have been added. Improved smart recording algorithms. This will improve track point dropping during turns. Increased detection radius for Elevation Points and added a detection message. Improved Course processing and error handling. Removed limitations on the displayed Power Calibration Value. Added notification messages for Courses, Workouts, and Metabolic Profiles. Added the ability to import. NLF New Leaf files. Fixed some issues with setting files not being saved properly. Improved Vertical Speed values. The Bike Profile page should now show an invalid value if the wheel calibration is set to Auto and not yet calibrated. Corrected issue transferring heart rate zones and power zones from Garmin Connect and Garmin Training Center. The bike odometer correctly updates during an activity. Cleanup of TCX conversion issues for courses. Corrected issues related to courses. Corrected issue with distance alert performance.

## Chapter 2 : Garmin: Edge Updates & Downloads

*Edge Owner's Manual START If you stray away from the course, the Edge displays an "Off Course" Page Workouts After you create a workout, you can use Garmin Connect or Garmin Training Center to schedule the workout for a particular day.*

Except as expressly provided herein, no part of this manual may be reproduced, copied, transmitted, disseminated, downloaded or stored in any storage medium, for any purpose without the express prior written consent of Garmin. Garmin hereby grants permission to download a single copy of this manual onto a hard drive or other electronic storage medium to be viewed and to print one copy of this manual or of any revision hereto, provided that such electronic or printed copy of this manual must contain the complete text of this copyright notice and provided further that any unauthorized commercial distribution of this manual or any revision hereto is strictly prohibited. Information in this document is subject to change without notice. Garmin reserves the right to change or improve its products and to make changes in the content without obligation to notify any person or organization of such changes or improvements. Visit the Garmin Web site [www.garmin.com](http://www.garmin.com). These trademarks may not be used without the express permission of Garmin. Firstbeat and Analyzed by Firstbeat are registered or unregistered trademarks of Firstbeat Technologies Ltd. Other trademarks and trade names are those of their respective owners. April Part Number Rev. See the Important Safety and Product Information guide in the product box for product warnings and other important information.

Charge the Edge page 2. Install the Edge page 2. Turn on the Edge page 4. Acquire satellites page 6. Go for a ride page 7. Save your ride page 7. Transfer history to your computer page 8. The Edge is powered by a built-in, lithium-ion battery that you can recharge using the AC charger or the USB cable included in the product box. Plug the AC charger into a standard wall outlet. Pull up the weather cap from the mini-USB port. Mini-USB port under the weather cap Tabs 3. To connect the Edge to your computer using the USB cable, see page 8. Charge the Edge for at least three hours before you begin using it. A fully charged battery can run for up to 18 hours before it must be recharged.

Installing the Edge For the best GPS reception, position the bike mount so the front of the Edge is oriented toward the sky. You can install the bike mount on the stem shown on page 3 or the handlebars. Select a suitable and secure location to mount the Edge where it does not interfere with safe operation of your bike. Place the rubber disk on the back of the bike mount. The rubber tabs align with the back of the bike mount so it stays in place. Place the bike mount on the bike stem. Attach the bike mount securely using the two bands. Bike mount notches Rubber disk Bands around the bike stem 5. Align the tabs on the back of the Edge with the bike mount notches. Press down slightly and turn the Edge clockwise until it locks into place. Turn the Edge clockwise to unlock the device. Lift the Edge off the mount.

Configuring the Edge The first time you turn on the Edge, you are prompted to configure system settings and user profile settings. Follow the on-screen instructions to complete the initial setup. GPS is turned off. Heart rate monitor is active. Speed and cadence sensor is active. Power meter is active. Press any button to extend the backlight for 15 seconds. Press and hold MENU to switch between menu and timer modes. Go outdoors to an open area. Make sure that the front of the Edge is oriented toward the sky. Wait while the Edge searches for satellites. Do not begin moving until the locating satellite page disappears. To turn off the GPS receiver and use the Edge indoors, see page 8. For heart rate monitor instructions, see page 8. Press and hold MENU to view the timer page. History is only recorded while the timer is running. After completing your ride, press STOP. Using Free Software Garmin provides two software options for storing and analyzing your ride data: Garmin Connect is Web-based software. Garmin Training Center is computer software that does not require the Internet after installation. Follow the on-screen instructions to install the software. Mini-USB port under weather cap 3. Open Garmin Connect <http://www.garmin.com>: Follow the instructions included with the software. Using Time, Distance, and Calorie Alerts 1. Press and hold MENU. Turn on the alert. Enter a time, distance, or calorie amount. Go for a ride. Each time you reach the alert amount, the Edge beeps and displays a message. To turn on audible tones for messages, see page 8. Select HR Alert to set the minimum and maximum heart rate in beats per minute bpm. For more information about heart rate zones and settings, see page 8. Select Power Alert to set the minimum and

## DOWNLOAD PDF GARMIN EDGE 500 MANUAL

maximum power amounts in watts. Each time you exceed or drop below the specified heart rate, cadence, or power amount, the Edge beeps and displays a message. This feature is helpful for comparing your performance over different parts of a ride for example, every 10 miles or 40 kilometers. Customize optional lap data fields page This feature is helpful for comparing your performance over different parts of a ride for example, a long climb or training sprints. Select Lap Press Only to trigger the lap counter each time you press LAP and each time you pass any of those locations again. Customize optional lap data fields see page During courses, use the By Position option to trigger laps at all of the lap positions saved in the course. This feature is helpful if your ride includes stop lights or other places where you need to slow down or stop. The paused time is not saved with your history data. Select When Stopped to pause the timer automatically when you stop moving. Select Custom Speed to pause the timer automatically when your speed drops below a specified value. Customize optional time data fields see page Using Auto Scroll Use the auto scroll feature to automatically cycle through all of the training data pages while the timer is running. Select a display speed: Slow, Medium, or Fast. The training data pages scroll automatically. You can press PAGE to manually switch pages. You can follow the course trying to match or exceed previously set goals. You can then transfer the courses to your Edge page You can add course points, or places on your course that you want to remember, such as water stops or distance goals. Select a previous ride on which to base your course. The Edge assigns a default name to your new course that appears in the list. Select the course from the list. Select Edit Course to rename the course. History is recorded even if you are not on the course. Press PAGE to view the data pages: Stay away from your course path as you warm up. When you are ready to begin, head toward your course. Use the course map or course points to find your way back to the course.

### Chapter 3 : Edge - Edge Owner's Manual

*The Edge attaches easily to the stem or handlebars of your bike with its low-profile bike mount. The Edge attaches easily to the mount with a simple quarter-turn. When you're ready to ride, just power on your Edge, acquire GPS satellites and go.*

### Chapter 4 : GARMIN EDGE OWNER'S MANUAL Pdf Download.

*Garmin Connect Community for tracking, Manuals for Edge® Manual Name Revision Revision Date Part Number Action;*

### Chapter 5 : Garmin Edge Owner Manual | Bookmarks and Contents

*2 Edge Quick Start Manual Charging the Edge notice To prevent corrosion, thoroughly dry the mini-USB port, the weather cap, and the surrounding area before.*

### Chapter 6 : Garmin Edge Cycle Computers & GPS | eBay

*Garmin EDGE Pdf User Manuals. View online or download Garmin EDGE Owner's Manual.*

### Chapter 7 : Garmin Edge Manual - Download Manual PDF Online

*Find great deals on eBay for garmin edge manual. Shop with confidence.*

### Chapter 8 : Garmin EDGE Manuals

*Garmin GPS Edge Owner Manual: Bookmarks and Contents, for online reading and free download.*